U-232

USB based Serial Port replacement

Version 2.0
Revision 5.4.24

TIMEWAVE

Quick Install

Insert the TIMEWAVE U232 Driver CD into your computer.

The Install Driver dialog should appear.   If not, run *U232VCPInstaller.exe* from the CD.

Click on *Install*.

The *Installation Successful* dialog will appear.   You may also get a restart dialog.

 or

If you get the restart dialog, click on "Restart Now" to reboot your computer.

The drivers are now on your system.   Connect the U232 based device.

If you are using Windows Vista or Windows 7, the *Ready to Use* notice will appear.   You are finished.

If you are using XP, the *Found New Hardware* notify box should appear.   If not, manually uninstall the driver from the *Device Manager* and reconnect.

The *Found New Hardware Wizard* should appear.   Click on *Next* to begin the driver installation.

The USB driver is now installed.

Next, the wizard will restart for the COM port driver.   Follow the same setup instructions as for the USB driver.

The COM driver is now installed and your COM port should appear.